

ROUGH OPENING WIDTH = FINISHED OPENING WIDTH + 1.25" ROUGH OPENING HEIGHT = FINISHED OPENING HEIGHT + .625"